

1.0.4 Chisel, square & round point tapers

[https://www.youtube.com/watch?v=4BjTItFIH7A&ab\\_channel=RowanTaylor](https://www.youtube.com/watch?v=4BjTItFIH7A&ab_channel=RowanTaylor)

1.0.5 Staple (to match Gate Latch Project) 7 inch 5/16 round

1.0.6 S-Hook; 1" ID 8 inch 5/16 round

Bending over the bick or horn [https://www.youtube.com/watch?v=-ESejG0pcGs&ab\\_channel=DF-InTheShop](https://www.youtube.com/watch?v=-ESejG0pcGs&ab_channel=DF-InTheShop)

1.0.7 Taper project: Leaf or Hook or other 1/2 inch round

1.0.8 Hand Held center punch or round punch 4141 (sucker), 6 1/2"

[https://www.youtube.com/watch?v=OV06XIMy88o&ab\\_channel=MarkAspery](https://www.youtube.com/watch?v=OV06XIMy88o&ab_channel=MarkAspery)

1.0.9 Hand held chisel 4140 (sucker), 7 1/2"

[https://www.youtube.com/watch?v=OV06XIMy88o&ab\\_channel=MarkAspery](https://www.youtube.com/watch?v=OV06XIMy88o&ab_channel=MarkAspery)

1.0.10 Hammer eye drift - short 4140 (sucker), 6.5"

[https://www.youtube.com/watch?v=MFkHRWg4Fj4&ab\\_channel=MarkAspery](https://www.youtube.com/watch?v=MFkHRWg4Fj4&ab_channel=MarkAspery)

1.0.11 Slotting punch to make hammer eye; 7/8x1/8 inch made to match drift 4140, 7 1/2"

[https://www.youtube.com/watch?v=MFkHRWg4Fj4&ab\\_channel=MarkAspery](https://www.youtube.com/watch?v=MFkHRWg4Fj4&ab_channel=MarkAspery)

1.0.12 Heat treat cold chisel, center punch

[https://www.youtube.com/watch?v=ovQkCbXJPbg&ab\\_channel=RussJennings](https://www.youtube.com/watch?v=ovQkCbXJPbg&ab_channel=RussJennings)

1.0.13 Monkey Tool 5/16 or Top Tool 1 inch square; case harden

[https://www.youtube.com/watch?v=Q-6akAaX-Ow&ab\\_channel=MarkAspery](https://www.youtube.com/watch?v=Q-6akAaX-Ow&ab_channel=MarkAspery)

1.0.14 Hand-held Fuller/simple Z bottom fuller 1/4" 4140, 7 1/2"

1.0.15 Round Tenon 5/16" diameter to match Monkey Tool 3/8 round

[https://www.youtube.com/watch?v=KZWfQjKCR8M&ab\\_channel=MarkAspery](https://www.youtube.com/watch?v=KZWfQjKCR8M&ab_channel=MarkAspery)

Use a tenon tool (ie. Smithin-Magician, Guillotine)

[https://www.youtube.com/watch?v=KZWfQjKCR8M&ab\\_channel=MarkAspery](https://www.youtube.com/watch?v=KZWfQjKCR8M&ab_channel=MarkAspery)

1.0.16 Round Drift (also called Pin Drift) 1/2 inch round bar; upset middle

1.0.17 Punch hole

[https://www.youtube.com/watch?v=qWcNn4PhFIY&ab\\_channel=BlackBearForge](https://www.youtube.com/watch?v=qWcNn4PhFIY&ab_channel=BlackBearForge)

1.0.18 Forge weld: Flux-Spoon and either trivet or Chain Links 3/8 round 6 inch 3/8 round

Make a forge-weld (i.e. drop tong, celery weld)

[https://www.youtube.com/watch?v=dNHSC0m7K0o&t=112s&ab\\_channel=MarkAspery](https://www.youtube.com/watch?v=dNHSC0m7K0o&t=112s&ab_channel=MarkAspery)

1.0.19 1.0.15 Barbed gate hook per drawing

Playlist of Presentation: <https://www.youtube.com/playlist?list=PLVYB6kRgOncBTNJUzR9-KylueLyqT7tvW>

Mark Asprey: [https://youtu.be/0ialfV\\_pm0Q](https://youtu.be/0ialfV_pm0Q)